



## PARALLELING D-SUB PINS:

DIVIDE AVERAGE CURRENT TO BE CARRIED BY 3. THIS DE-RATES EACH PIN TO 3A AVERAGE CURRENT. INSTALL 12" 22AWG WIRE IN EACH PIN. IF CABLE/CABLE CONNECTOR, PUT 6" IN EACH SIDE. IF CABLE/ECB CONNECTOR USE 12" IN CABLE SIDE CONNECTOR. DROP PIGTAILS INTO BUTT SPLICE. EXTEND SPLICED PIGTAILS WITH SINGLE STRAND RATED FOR THE TASK AT HAND.