

S700-2-50

S700-1-3

ENGINE

LEFT IGN OFF

RIGHT IGN OFF

PUSH STARTER

FUEL PRIME OFF

DC POWER

E-BUS ALT FEED OFF

AUX BATTERY OFF

DC PWR MASTER OFF

MAIN ALT 5

AUX ALT OFF

AUX ALT 5

PITOT HEAT OFF

LIGHTS

LANDING LIGHT OFF

POSITION LIGHTS OFF

STROBE LIGHT OFF

S700-2-10

S700-1-3

ALL ELECTRIC AIRPLANE ON A BUDGET (FIGURE Z-13) AND DUAL BATTERY (FIGURE Z-30)

