


FIGURE Z-14 ARCHITECTURE FOR REAR BATTERIES



* IF YOU PLAN TO CLOSE XFEED CONTACTOR FOR STARTING, MAIN BAT FEED CAN BE 4AWG. IF YOU CRANK WITH XFEED CONTACTOR OPEN MAIN BATTERY FEED IS 2AWG.