



- NOTES
1. THIS GROUND TERMINAL IS USED TO KILL MAGS BY WAY ENGINE GROUND SECURED THROUGH SHIELDS ON IGNITION CONTROL WIRES. DO NOT CONNECT THIS GROUND TO ANY OTHER CONDUCTORS IN THE COCKPIT.
  2. THIS GROUND IS STRAPPED TO THE "R" MAG TERMINAL ON MAGNETO EQUIPPED ENGINES ONLY. DO NOT USE THIS TERMINAL ON THE ROTAX ENGINE INSTALLATION.